

YEAR 2017 SPEEDPLAY ROAD SHOE COMPATIBILITY GUIDE**

ZERO, ULTRA LIGHT ACTION OR X SERIES PEDALS WITH V.2 CLEATS

WARNING! - Use only V.2 Cleat Fastening Screws supplied with V.2 Cleats Do NOT use previous versions of Cleat Fastening Screws with the V.2 Cleats. All previous versions of Cleat Fastening Screws are too short for use with V.2 Cleats and can affect the engagement and retention of the pedal system which can lead to a fall that can result in severe injury. **Never install cleats using any combination of new cleat parts and old cleat parts** When replacing cleats, replace all used parts with new V.2 parts.

NOTE: VARIATIONS IN SHOE SOLE CURVATURES MAY REQUIRE SNAP SHIMS OTHER THAN THOSE RECOMMENDED BELOW. PLEASE VISIT OUR WEBSITE AT WWW.SPEEDPLAY.COM TO SEE OUR CLEAT INSTALLATION VIDEO UNDER TECH SUPPORT / VIDEO LIBRARY.

2017 MODEL SHOES COMPATIBLE WITH FACTORY-INSTALLED 5-F AND 5-R SNAP SHIMS

Bont 3 hole // Bontrager Nylon // Bontrager Silver Series Carbon // Exustar // FLR // Giro Carbon // Lake // Mavic // Nalini Carbon
Northwave // Scott Carbon // Serfas-Nylon // Specialized // Suplest

SNAP SHIMS REQUIRED FOR NON-STANDARD 2017 MODEL SHOES AND PRIOR YEAR MODEL SHOES

Answer	2009 & earlier	Use 5-F & 5-R Snap-Shims.
Bont - 3 hole	2017 & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Bontrager - Carbon	2017 & earlier	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Carnac	2011 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Carnac Insert-type	2011 & earlier	Omit V.2 Base Plate. Use Carnac-supplied UCS3 insert. Requires Speedplay V.2 4x16mm Cleat Fastening Screws (Part #14030).
CHAIN - Carbon	2012 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
CHAIN - Nylon	2012 & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Diadora - Nylon, Carbon, Votex Pro	Current year & earlier	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Diadora Alu	Current year & earlier	Call Speedplay for installation instructions. 1-800-468-6694.
Diadora Multipied	Current year & earlier	Omit V.2 Base Plate. Use Diadora-supplied Time/Speedplay insert.
DMT	2007 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
DMT - Insert-type	Current year & earlier	* Remove Snap-Shims from V.2 Base Plate. Sole must be modified to allow rearward cleat adjustment. See photo at www.speedplay.com .
Duegi	2008 & earlier	Use 5-F & 5-R Snap-Shims.
Exustar	2012 & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Fizik	2013 - 2017	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Gaerne	2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Giro - Nylon & Carbon	2012 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Kuips	2011 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Lake Carbon & Nylon	2011 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Lake Carbon & Nylon	2017	Use 5-F & 5-R Snap-Shims.
Look	2007 & earlier	Use 5-F & 5-R Snap-Shims.
Louis Garneau - Carbon Compo / Carbon X-Vent / Compo X-Vent / Ergo Air Nylon / HM X-Lite	2007 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Louis Garneau Carbon Ergo	2012 & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Luck	2009 & earlier	Use 5-F & 5-R Snap-Shims.
Nalini Carbon	2009 - 2011	Use 5-F & 5-R Snap-Shims.
Nalini	2008	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Nalini CARBONALINI sole	2009	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Nike	2009 & earlier	Use 5-F & 5-R Snap-Shims.
Northwave Speedplay	2012 - 2017	Omit V.2 Base Plate. Requires Northwave-supplied kit: NW Speedplay adaptor (Available through Northwave).
Northwave Centurion, Mirage, Solo, Diana Road, Husky	Current year & earlier	Omit V.2 Base Plate. Use Northwave-supplied Time/Speedplay insert. Requires V.2 4x13mm Cleat Fastening Screws (Part #14020) available from Speedplay.
Pearl Izumi	2012 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Pearl Izumi	2011	Use 5-F & 5-R Snap-Shims.
Pearl Izumi	2010 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Pearl Izumi I Beam Sole	2010 & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Scott - Carbon	2010 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Scott - Nylon	2011 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Scott - Nylon	2010 & earlier	Use 5-F & 5-R Snap-Shims.
Serfas - Carbon	2013 - 2016	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Shimano	2017 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
SIDI - Carbon Comp / Carbon Millenium III / Vent Carbon/ Carbon Millenium 4	2017 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Sidi Carbon Lite & Sidi Glass Fiber Comp	2012	Use 5-F & 5-R Snap-Shims.
Sidi - Eleven / Millenium III / Millenium 4/ Twelve	2013 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
SixSixOne	2008 & earlier	Use 5-F & 5-R Snap-Shims.
Specialized (FACT Soles & Nylon/Glass Reinforced Soles)	2010 - 2017	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims.
Specialized Full Carbon Pro Models	2009	Use 5-F & 5-R Snap-Shims.
Specialized NON Carbon Models	2009	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims.
Specialized	2007 - 2008	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims.
Time	2009 - 2012	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Time	2008 & 2006	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Vittoria	2011 - 2017	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Vittoria	2009 & earlier	Use 5-F & 5-R Snap-Shims.
Wellgo	2010 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims.
Xpedo	2012 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims.

*** Ensure the factory-installed cleat nuts remain in the V.2 Base Plate.**

Shoes with 4-hole cleat pattern (Speedplay V.2 Base Plate not used).

adidas / Bont / DMT / Lake / Rocket 7 / Sidi / Vittoria / Gaerne / Rivo / Pinnacle Racing	Current year & earlier	Omit V.2 Base Plate. See note below regarding 4-Hole Carbon Fiber Soles.
---	------------------------	--

INCOMPATIBLE SHOES

adidas	2007 - 2008	Nalini Nylon	2011 - 2013
DMT Mag Force & Mag Light	2008	Northwave Carbonio	Current year & earlier
Exus	Current year & earlier	Scott Full Carbon Power Transfer Sole	2009
Lake CX 401	2010 & earlier	Scott - Road Ltd.	Current year & earlier
Lake 115 & 125	Current year & earlier	Shimano WITHOUT 3-Hole (Look) pattern	Current year & earlier
Mavic	2009 & earlier	Shimano Carbon Fiber	2004 & earlier
Nalini Carbon	2012 - 2013	All MTB shoes and road shoes with MTB-type lugged soles	Current year & earlier

4-Hole Carbon Fiber Soles: Must use the V.2 Protector Shim Kit (Part #14015), sold separately and available from Speedplay, to prevent contact between the pedal body and the carbon-fiber sole. Carbon fiber is a poor wear surface and unless a wear protector is used, damage to both the pedals and shoes will result.

WARNING! - Do not use the Snap-Shim Cleat mounting screws with any previous models of Speedplay X cleats including the Slim Line Cleat. The Snap-Shim Cleat mounting screw heads are too small and may pull through the older base plates. This may cause the cleat to pull off the shoe causing a fall that may result in severe injury.

**** See detailed photos of select sole mountings and the latest updates for shoe compatibility at www.speedplay.com or call the Speedplay Tech Department at 1-800-468-6694 (PST).**